mD Guide DRILLWITH ACCURACY RAPIDITY

Select a drill with a cylinder that matches the mesio-distal size of the missing tooth. As you lay it against the adjacent tooth while drilling your pilot hole, your implant is perfectly aligned with the future crown.



Select the matching virtual crown and insert it into the pilot hole. Select a pilot drill and lay it against the virtual crown! Drill a second pilot hole. And so on! No matter the number of implants (here a bridge)



- An essential medio-distal guidance without changing your habits, your protocole or your implants
- Your implants will be perfectly «self» aligned with your futur crowns.
- One hand and is enough. No need to hold any additional accessory
- You don't any more surgical guide.

DRILL(HERE



Please, do not



